

Ryder Towing

TF2323 SmartCan2 Fitting Guide

13pin Lights Only

Interfaces directly to CAN



Contents of the kit

- 1 x SmartCAN2 module
- 1 x 13-pin socket with seal and fixing screws
- 1 x complete set of wires
- 1 x fuse tap connector with 15 amp fuse
- 2 x Red Positap connectors
- 1 x ring (earth) terminal
- 1 x Blue butt connector
- 2 x snap connectors (Scotchlocks)

The TF2323 SmartCan2 towing module connects directly to the vehicle's CAN bus network. All the signal data to the towing module comes from a direct connection to the vehicle's CAN HI, CAN LO wires.

Programmed to the vehicle.

The Bootloader interface programme's the module to the car. You may choose to have a Bootloader yourself, or we will programme your module to a specific vehicle before dispatching it to you.

You can also manually re-programme the SmartCAN2 module without a Bootloader if needed.

Warnings

- Disconnecting the battery: If you do disconnect the battery, make sure the ignition is switched off before you disconnect. Only disconnect for the shortest possible time.
- NOTE: The connections to CAN HI and CAN LO have to be excellent, and soldering is not recommended because of potential heat transfer to sensitive circuits in the car, so each kit includes two red Positap connectors. We strongly recommend their use for this interface.

Overload protection: As well as the fuse protection you put on the input cables, the module has on board protection against overloads - it will shut down any lighting circuit that shorts, etc. In service, making this a very durable unit.

The module sends trailer data back to the vehicle: Some vehicles automatically accept data back from the unit and alter some functions when a trailer is connected.

(Check the compatibility list on our website to see if your vehicle is compatible and has access to extra trailer functions.)

WARNING - Please take note important information: The indicator tell buzzer/C2 system is inverted in this system so the buzzer won't sound unless there is an issue with the indicators on the trailer.


If an indicator bulb is out then the module will also temporarily substitute the corresponding side light bulb as a turn signal until the issue has been resolved. It is advised to wire the side lights separately because of this feature.

For 12S/full function, have a look at TF2324.

Ryder Towing

TF2323 SmartCan2 Fitting Guide

13pin Lights Only



Ryder Towing

TF2323 SmartCan2 Fitting Guide

12N version

Procedure

1. Look at vehicle specific instructions find CANbus connection points and select area to install the module into the vehicle and remove paneling as required.
2. Disconnect the battery.
3. Find a good earth point and connect the white wire from the module, using the ring terminal provided.
4. Thread the sleeved wires out of the car and connect to the 13-pin socket. Connect the socket to the mounting plate.
5. Lead the wires from the module through the vehicle to the appropriate CANbus connection points found earlier.
6. CAN 1: Use the instructional pictures provided to identify the CAN connection points, Cut the twisted pair from the module's CAN wires to length and connect to the vehicle's CAN wires using the push on connectors provided.
7. CAN 2 (Vehicle dependent optional check compatibility list)
The extra CAN wires pin 5 (CAN lo - Purple) and pin 6 (Can hi - Yellow and Purple) on the module plug. Fit the other ends to the vehicle's CAN second set of CAN wires as indicated on the installation instructions if required.
8. Hard brake connection (If needed - See diagram on vehicle specific instructions)
Take the red wire from pin 7 of the module and connect it to one of the wires to the brake lights, using a snap connector (Scotchlok). This provides an optional analogue backup to the braking system. It is required in some European countries.)
9. Power connection
The red wire that runs from both pins 15 and 18 is for power to the module.
Use either the Fusetap connector provided to take power from the vehicle's fuse box in a suitable fuse slot, or the crimps for a hard battery connection and check your installation then insert the 15amp fuse in the Fusetap and test.
10. If you are using AutoSCAN, make sure the module has been updated with latest software with **no vehicle program pre-installed**, turn on the vehicle ignition and turn on the hazard lights, plug in the module and press and hold the button by the white connector on the module and the LED will start flashing, after about 10 seconds the LED will stop flashing and stay on, stop pressing the button and autoSCAN will start and can take up to 60 seconds, once done the module will resume normal operation and be programmed to the vehicle, Run operation tests.
11. If you are re- Programming the module, if you are using the bootloader make sure the module has been updated and programmed correctly to the vehicle using the TX2303 and follow instructions (See note below)
12. Restore all paneling etc.

Note: The module may have been programmed to the car by us before dispatch or you may have chosen to have your own Bootloader unit to set it up for the car you are fitting to.

Alternatively, you can programme it using the AutoSCAN feature.

If you scan the top QR code on the right, you will see a YouTube video showing how to do this.

The programme codes can be found on the compatibility PDF lists on the Ryder Towing website at this address www.rydertowing.co.uk/download/car-data. Or scan the below QR code on the right.

Ryder Towing

TF2323 SmartCan2 Fitting Guide

12N version

Warranty conditions

We would expressly point out that any installation not carried out by a competent installer will result in the cancellation of any right to damage compensation, in particular, those arising under the product liability act.

Contents of these kits and their fitting manuals are subject to alteration without notice.

Please ensure that the instruction manual is read and fully understood before commencing installation.

Do not overload circuits.

**Compatibility List
Downloads**



**You Tube Video for
AutoSCAN operation on
module.**

