



The wires from the 14-way plug connect to the vehicle loom, as shown above.

The two grey wires are non-polarised, for the reverse circuit. Connect one to the car's reverse circuit and the other to +12V.

The pink loop makes the relay negative switched.

The single orange wire is the power input from the fusebox and should be fused close to the power source, 15 amps.