## TF2218/7TP24 for Pickups and Tippers

Potted for external fitting All outputs by wire

Input signalwires, power wires and C2 twin, sleeved 2 metres Wire in cab.

Output wires,7-core 0.75mm2 5 metres



TF2218/7TP24 with Twin for C2 (Buzzer)

Signal input wires all 2.1metres long fully sleeved

Yellow LH indicator
Blue Foglight
White Earth to chassis
Green RH indicator
Brown RH tail

Brown RH tail
Red Brakes
Black LH tail
Grey Reverse

Orange +24V (fuse 10 amps) Orange +24V (fuse 10 amps)

Twin wire

Black C2

Black/white C2 return

Check polarity

**DO NOT** remove the fuse connectors from the 2 orange power wires.

## Doing so will void any warranty on the relay.

The 2 x 10A fuses are needed alongside an external 15A fuse for circuit protection on the TF2218/7TP relay.

TF2218/7TP24 with Twin for C2 (Buzzer) Potted

To wire reverse on a twin 7-pin installation, bring the brown wire across to the 12S socket and wire it to 12S Pin 1.
On a 13-pin installation, wire brown to Pin 8.

Output wires 0.75mm2 in place of screw terminals 5 metres long fully sleeved.
Wire to trailer socket

		Pin
Yellow	LH indicator	1
Blue	Foglight	2
White	Earth	3
Green	RH indicator	4
Brown	Reverse 13-pin	8
Red	Brakes	6
Black	BOTH LH and RH tail	7

## NOTE:

Brown output is for reverse Black is for both sidelights Put a loop in the socket between pins 5 and 7

Quality - Service - Innovation

Unit 1, Chadwick Block, Bracewell Ave Poulton-le-Fylde, Lancashire, FY6 8JF, Phone: 01253 881008 (Fax: 01253 886434)

(www.rydertowing.co.uk mail@rydertowing.co.uk)