
## Ryder Towing Equipment Ltd

## **TF1013 LED filter application**

Use a TF1013 in the towing vehicle to prevent its OEM module pulses flashing LEDs on trailer tail and brake circuits

Cut brown and black wires in 7-core cable to trailer socket and fit the TF1013 in line as shown below.



Power from battery
7-core brown to socket
7-core black to socket

If there is also a pulse on brake LEDs connect black to module LH tail output red to module brake output

If there is also a pulse on brake LEDs connect both 7-core black and brown to terminal 5/7 and 7-core red to terminal 6